


USER GUIDE




Table of content

١.	Wiring plan	2
II.	Presentation of the controller	3
III.	Setup and application	4
Δ	A. Main page	4
	How to set the system language	5
	How to connect to the Wi-Fi network?	7
В	B. Application launch	11
	Authentification	12
	Channels	14
C	C. How to clear the app's cache	16
IV.	Error codes	18
V.	How to set up your game controller	20
Д	A. Set up	20
В	B. For PS4 controller	20

I. Wiring plan




II. Presentation of the controller



III. Setup and application

A. Main page



How to set the system language

Settings





Device Preferences





Language

(Then select the language of your choice)









How to connect to the Wi-Fi network?

Settings



Networks & Internet





Select your network





Insert the password

(Then press the key \rightarrow | on the virtual keyboard)










Connecting to TP-LINK_8170_5G

Connected successfully


B. Application launch

Go back to the home page by pressing (10) Then launch the **BravoTV** Application (from the favourites)




Authentification

Authenticate yourself with the login details that you received in your email





Enter your name



 Once the process is completed, you will be automatically redirected to the application's main page




Channels

 To access all the channels available in your package, navigate to the "TV" section



 The "EPG" section gives access to the programs in detail with start and end times



 The "Settings" section gives access to the players' version and to your account information





Never disconnect from the app after the first login The player might not be able to read the stream anymore

(The box can be turned off or restarted without any problem)

C. How to clear the app's cache

Hold down the confirm button (7) on the application (2s)




Info





Empty the cache



Confirm







IV. Error codes

When the BRAVOTV application is installed, a serial number and an identifier will be automatically created in association with the mac address of the physical equipment, this set represents an equipment for the management system.

For proper operation, each customer account must be associated with its equipment

EC02 – represents the unavailability of the equipment

EC02 - The equipment is associated to another account

EC06 – When you reach the maximum number of equipment to add

EC10 – Wrong login used during authentication Wrong username or password

EC11 – When the equipment is disabled

EC12 – When the equipment is not associated with a user account

EC21 – When the equipment type is not authorized

EC50 – When there is an attempt to connect from an unauthorized specific IP to a login sharing case where two devices try to connect with the same credentials at the same time

EC55 – When the client IP is blocked

Following attempts from multiple devices with the same public IP using the same login from the same account

Or

When the same equipment tries to connect several times

WB0051 _ When the client connects from an unauthorized IP (other ISP)

EC300 - When the API is blocked

This happens when the management platform is disabled so users will not be able to authenticate

V. How to set up your game controller

A. Set up

- 1. On the front of your game controller, hold down the switch. After three seconds, you will see four lights flashing.
 - If the lights are not flashing: press and hold the Back and Home buttons
- 2. From the Android TV home screen, scroll down to Settings.
- 3. Under "Remote Control and Accessories," select Add Accessory.
 - 4. Select your game controller.

B. For PS4 controller

- 1. On the DualShock 4 controller, hold down the **PS** and **SHARE** buttons to put it in pairing mode.
- 2. Make sure the light starts flashing.
- 3. On your Android device, go to


Settings ▼

Remotes & Devices


ccccccr


Add accessory


Select the controller




▼ Synchronize










Install and launch your favorite game apps





ENJOY!